

Mailbox Greeting Management

Your mailbox greeting identifies your mailbox to outside callers. Outside caller near your *Active Greeting*, initially greeting one, when they first reach your mailbox

To record a mailbox greeting:

- Access your mailbox.
- Press <u>3</u> to access the *User Options Menu*.
- Press 2 to access the *Mailbox Management Menu*.
- Select 2 to record a new greeting.
- Enter the greeting to record, the Active Greeting.
- Record your greeting when prompted.
- Press * to stop recording.
- Press 4 to save it.

Mailbox Pass Code

To select a pass code:

- Access your mailbox.
- Press <u>3</u> to access the *User Options Menu*.
- Press <u>3</u> to select a pass code.
- Enter the pass code when prompted.
- Enter the pass code again for verification.

Subscriber Features

Distribution List Menu

Each user has nine available Distribution Lists with forty available mailbox slots on each list.

- 1 Create a Distribution List
- **2** Add or Delete a mailbox
- 3 Playa Distribution List
- 9 Return to User Options Menu

To create a distribution list:

- Access your mailbox.
- Press 3 to access the *User Options Menu*.
- Press $\overline{4}$ to access the *Distribution List Menu*.
- Press 1 to create a new list.
- Enter the number of the list you wish to create (1-9).
- Record the list name when prompted.
- Press # to stop recording.
- Press 4 to save it.
- Press $\underline{\mathbf{1}}$ to add mailbox numbers to the list.

To modify a list:

- Access your mailbox.
- Press <u>3</u> to access the *User Options Menu*.
- Press 4 to access the *Distribution List Menu*.
- Press $\overline{2}$ to add or delete a mailbox.
- Enter the number of the list you wish to modify (1-9).
- Press <u>1</u> to add mailboxes, or Press <u>2</u> to remove mailboxes.
- Enter mailbox numbers when prompted.
- Press # when you are finished.

To review a list's members:

- · Access your mailbox.
- Press <u>3</u> to access the *User Options Menu*.
- \bullet Press $\underline{\mathbf{4}}$ to access the Distribution List Menu.
- Press $\overline{\underline{3}}$ play a list's members.
- Enter the number of the list you wish to review (1-9).
- The VMI will play all of the mailboxes on that list.

Time/Date Feature

You can turn the message Time/Date Stamp off or on. If you turn off the Time/Date Stamp, the Omega-Voice VMI plays the message without first announcing the time and date. To obtain the time and date for a message you can press 8. When the Time/Date Stamp is turned on, the VMI plays it before playing the message. The Omega-Voice VMI is initially programmed to play the time and date stamp for all messages in all mailboxes.

To change the time and date stamp format for messages:

- Access your mailbox.
- \bullet Press $\underline{\mathbf{3}}$ to access the User Options Menu.
- Press $\underline{7}$ to select the time/date stamp.

Press $\underline{\underline{1}}$ to turn on the Time/Date stamp.

Press $\underline{2}$ to turn off the Time/Date stamp.

- The VMI confirms that your selection has been saved.
- Your selection applies to all messages.

Message Replay Order

You may select the replay order of you r messages, either first-in, first-out (FIFO) or last-in, first-out (LIFO). When FIFO is selected the oldest message is played first. When LIFO is selected the newest message is played first.

To select the message replay order for message folders:

- Access your mailbox.
- Press 3 to access the User Options Menu.
- Press 8 to select message play back order.
 Press 1 to play oldest message first.
 Press 2 to play newest message first.
- The VMI confirms that your selection has been saved.
- Your selection will immediately apply to all messages in all folders except the receipt folder. The oldest message in the receipt folder will always play first.